

MCF / MCF-E3

Mixer




Description

The mixer has an inner thread allowing for installation on the resin cartridge mouth. The mixer has an internal spiral that allows for extruding of the resin and mixing it with the hardening compound. Proper mixing is necessary for achieving proper durability parameters of the connection.

Caution: In case of a break during application for longer than 10 min (20 min for E3), you should replace the mixer with a new one and clear the resin off of the cartridge mouth.

Characteristics and advantages

Universality	One type of mixer for various resin types
Extruding control	Transparent plastic allows you to control the movement of resin in the mixer

Code	For use with injection anchors	Pcs. 
MCF	<ul style="list-style-type: none"> WCF-PESF-300, WCF-PESF-E-300, WCF-PESF-C-300, WCF-VESF-300, WCF-VESF-E-300, WCF-VESF-410, WCF-VESF-E-410, WCF-EASF-410, WCF-EASF-E-410, WCF-EASF-C-410, 	12
MCF-E3	<ul style="list-style-type: none"> WCF-E3-585 	12

